Quick IRONGATOR engineer's vice with quick moving system

721Q/6-US



Profili

Atributi proizvoda

- Kućište od sivog lijeva
- Čeljusti od ugljičnog čelika, kovane, ojačane i zakaljene
- Kućište lakirano, čeljusti zaštićene od korozije, ostali dijelovi pocinčani
- UniPRO vodilice omogućavaju precizan rad pokretnih dijelova
- Štega se može kombinirati sa okretnim postoljem
- Škripac brzog pomicanja



	B	L	L	D	H1	a	b	H	L1	B1	
625130	125	120	336	17 - 62	95	66	44	176	132	90	14500
625131	150	140	400	20 - 75	117	80	53	211	154	105	23500

* Slike proizvoda su simbolične. Sve dimenzije su u mm, masa je u g.

Accessories


Okretno postolje za škripce 721/6 i 721Q/6


Rezervne čeljusti za 721/6 i 722/6, aluminijske

Rezervni djelovi


Rezervna čeljust za 722/6


Rezervne čeljusti za 721/6 i 722/6, aluminijske

Safety tips

- Avoid clamping with heavy pressure on the corner of the vice jaws as it may break off a corner of a jaw.
- Replace a bent handle as soon as possible.
- Use bolts in all of the holes in the base of the vice.
- Use lock washers under the nuts.

- Don't use the jaws of a vice as an anvil.
- Never use an extension handle for extra clamping pressure.
- Never pound on the handle to tighten beyond hand pressure.
- Never try to repair a vice by welding or brazing.
- Don't try to bend a heavy rod in a light

● When work is held in a vice for sawing, saw as close to the jaws as possible to prevent vibrations. Be careful not to cut into the jaws.

● When clamping extra long work, support the far end of work rather than putting extra pressure on the vice.

● Regularly lightly oil all moving parts.

● If the threaded part of the vice is exposed, keep it free of chips and dirt.

● Discard any vice that exhibits the slightest hairline fracture.

● Always use a vice large enough to hold the work without strain.

vice.