

# VDE elektricien schroevendraaier, TBI sleuf





Standaard

DIN EN IEC 60900 (VDE 0682-201):2019-04; EN IEC 60900:2018

#### Product attributen


- lemmet: Chrome-vanadium-molybdenum staal, volledig gehard en getemperd
- zwarte tip

- handvat: ergonomische vorm
- drie componenten materiaal
- met gaatje om op te hangen
- gemaakt volgens norm DIN EN IEC 60900 (VDE 0682-201):2019-04; EN IEC 60900:2018

 $\left( \right)$ 

• made according to standard ISO 8764-1,2

axb



	axb	С	L	<b>1</b>
616436	0.4 x 2.5	75	160	33
616437	0.5 x 3.0	100	185	37
616438	0.6 x 3.5	100	185	39
616439	0.8 x 4.0	100	185	43
621247	1.0 x 4.5	125	225	75
616440	1.0 x 5.5	125	225	75
616441	1.2 x 6.5	150	260	113
616442	1.2 x 8.0	175	295	163
621248	1.6 x 10.0	200	320	115

\* Afbeeldingen van producten zijn symbolisch. Alle afmetingen zijn in mm en gewicht in gram. Alle vermelde afmetingen kunnen variëren in tolerantie.

### Gebruik (Afbeeldingen)



Groot handvat voor meer torsiekracht.







Ergonomisch handvat = bescherming voor uw hand



Groot contactvlak = meer draaikracht









• Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.

• Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.

• A rounded tip should be redressed with a file; make sure edges are straight.

• Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.

• Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.

• A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.

• VDE tools that have several parts, have to be assembled correctly before use.

• When working with VDE tools avoid contact with water.

• Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.

• Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.

• Don't use a screwdriver with a split or broken handle.

• Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

• Don't use tools that shows sign of wear and have the second layer of plastic visible.

## Veelgestelde vragen

Are insulated (VDE) tools considered as personal protective equipment (PPE)? According to EU regulations, VDE tools are not considered as PPE.

#### Are the VDE tools only being sampled in series production?

The high voltage test (at 10kV) is performed fully on each tool. Other tests are performed in accordance with the EN60900 standard.