

# Giravite per elettricisti con lama isolata VDE



### Profili



## Standard

DIN EN IEC 60900 (VDE 0682-201):2019-04; EN IEC 60900:2018

#### Attributi del prodotto

- lama: acciaio al cromo vanadio hard premium, interamente bonificato e temprato
- punta brunita


- impugnatura: di forma ergonomica
- impugnatura: polipropilene
- foro per appendere
- conforme allo standard DIN EN IEC 60900 (VDE 0682-201):2019-04; EN IEC 60900:2018

(

L

 $\bigcirc$ 

•





axb

	axb	С	L	1	$\bigcirc$
616470	0.4 x 2.5	75	160	33	
616471	0.5 x 3.0	100	185	37	
616472	0.6 x 3.5	100	185	39	
616473	0.8 x 4.0	100	185	43	
616474	1.0 x 5.5	125	225	75	
616475	1.2 x 6.5	150	260	113	
616476	1.2 x 8.0	175	295	163	
616477	1.6 x 10.0	200	320	115	Till end of stock

\* Le immagini dei prodotti sono puramente simboliche. Tutte le dimensioni sono in mm, peso in grammi.

#### Utilizzo (pictures)





## Safety tips



• Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.

• Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.



• Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.

serraggio

• A rounded tip should be redressed with a file; make sure edges are straight.

• Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.

• Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.

• A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.

• VDE tools that have several parts, have to be assembled correctly before use.

• When working with VDE tools avoid contact with water.

# Frequently asked questions

• Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.

• Don't use a screwdriver with a split or broken handle.

• Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

• Don't use tools that shows sign of wear and have the second layer of plastic visible.

#### Are insulated (VDE) tools considered as personal protective equipment (PPE)?

According to EU regulations, VDE tools are not considered as PPE.

#### Are the VDE tools only being sampled in series production?

The high voltage test (at 10kV) is performed fully on each tool. Other tests are performed in accordance with the EN60900 standard.