

Crank Saver Kit

1695MB1-US



Profiles



Product features

- Crank Saver - Pedal thread repair and insert kit
- No more problems with stripped pedal mounting threads on the cranks. With the help of our Crank Saver Kit you can repair stripped threads and save your beloved cranks.
- First use reaming taps and create oversized 5/8"×24 TPI threads in the crank arms. Thoroughly clean the threads, then apply thread locker to the insert and install it into the crank arm. Finally, thread the pedal into the insert.
- For detailed instructions on Crank Saver Kit usage and inserts installation check the video below.

Kit includes:

- Left and right reaming tap 5/8"×24 TPI

- 10 pedal thread inserts for left crank arm
- 10 pedal thread inserts for right crank arm
- Kit comes in the metal box with cut out SOS foam trays, so each of the pieces will be always in the right place.

Product name	SKU	Article	Dimensions	Quantity
Crank Saver Kit	626980	1695MB1-US	-	5
Trajtuar për çezmat pedale		1695/4BI-US		1
çezmat pedale		1695.1AL	5/8" x 24 TPI	1
çezmat pedale		1695.1AR	5/8" x 24 TPI	1
Fut fije pedale, 10 copë vendosur, lënë		1695.4A	5/8L x 24	1
Fut fije pedale, 10 copë vendosur, e drejtë		1695.3A	5/8 x 24	1
Kuti metali		981K3/8R	3/8VDEx321x198x54	1

* Imazhet e produkteve janë simbolike. Të gjitha dimensionet janë në mm, pesha në gram. Të gjitha dimensionet e listuara mund të ndryshojnë në tolerancë.