

**1** Prikaz funkcije orodja**Tool function**

- 2** Vodili orodja z navoji vstavite v okvir. Vodili orodja za standard ITAL se na levi (stran, kjer ni pogona) in na desni strani (stran, kjer je pogon) okvirja privijata v desno (privijanje v smeri urinega kazalca).

**Install the bushings in to the bottom bracket shell.** Bushings of the tool for ITAL standard are using right hand thread for both left (non drive side) and right side (drive side) of the frame. Screw them in turning clockwise.

**2.1** Standard ITAL / desni navoj**ITAL standard / Right hand thread**

- 3** Vodili orodja z navoji vstavite v okvir. Pri standardu BSA ima leva stran okvirja (stran, kjer ni pogona) desni navoj, desna stran okvirja (stran, kjer je pogon) pa levi navoj. Vodili sta označeni z R (desna) in L (leva). Označbe označujejo smer navoja na vodilu in NE stran uporabe na okvirju.

**Install the bushings in to the bottom bracket shell.** Left side of the frame (non-drive side) uses right hand thread and right side of the frame (drive side) uses left hand thread. Bushings are marked with R (right) and L (left), designating the direction of threading. NOT the side of the frame in which the bushing is used.

**3.1** Standard BSA / LEVI ter DESNI navoj**BSA standard / RIGHT and LEFT hand thread**

- 4** Vodili v okvir privijete s pomočjo ploščice za privijanje, ki je priložena orodju. **Use metal plates provided with the tool to screw bushings in to the bottom bracket.**

Skozi vodila vstavite orodje in ga sestavite, kot je prikazano na sliki.

- 5** Za pravilno delovanje je treba robinlike naoljiti. V nasprotnem primeru rezultati dela ne bodo optimalni, orodje in/ali okvir pa se lahko poškodujeta.

**Insert the tool through bushings in to the bottom bracket shell of the frame.** Assemble the tool as shown on the picture.

**For best results make sure to oil the reamers before you start. Failing to oil the reamers can result in damage to the frame and/or the tool.**

- 6** Namestite ročaj orodja v magnetni utor za ročaj.

**Install the magnetic handle in to the designated groove.**

- 7** Za pravilno nalačanje orodja matico pod vzmetjo privijte za nekaj obratov. Pričnite z obračanjem ročaja v desno (v smeri urinega kazalca).

**Make sure the reamer is seating correctly in to the frame.** Thread the tension nut to compress the spring and add some tension to the tool. Start turning handle clockwise.

- 8** Ponovimo korake 2–6 na drugi strani glave okvirja.

**Repeat steps 2 – 6 on the other side of the head tube.**

Za natančnejša navodila o uporabi orodja, obiščite naš youtube kanal UniorBikeTools.

*For more detailed instructions of the tool, check our youtube channel UniorBikeTools.*



**Unior d.d.**  
Kovaška cesta 10  
3214 Zreče, Slovenia  
T: +386 3 757 81 00  
[www.uniorbiketools.com](http://www.uniorbiketools.com)

**1699****EN****Bottom bracket facing tool  
BSA & ITA****SLO****Robilnik ležišč šalic  
gonilnega ležaja BSA&ITA**

**UNIOR**  
BIKE TOOLS  
[uniorbiketools.com](http://uniorbiketools.com)

