



ENG

Material for fixing the substrate advertisements

Depending on the type of surface (brick, concrete, steel, ...) on which is placed advertisements, should take adequate screw and screw anchors. For setting the metal substructure fixed advertising self-tapping screw- Required diameter screw $\phi 6\text{mm}$, length of the screw depending on the type of substrate and insulation layers as possible.

Installation Procedure:

1. Open click frame
2. Remove the front display with graphics
3. At the base sheet metal make holes $\phi 8\text{mm}$ in positions that correspond to the situation and place of installation taking care not to damage installed electrical installation.
4. Positions holes transferred to the based, and the same to prepare for setting advertising.
5. Through the introduction of cable install power cable in the advertisement. Power cable PPY 3x1.5 provides ad investor. at the request of pziciju editorial cable to the advertisement can be defined by customer.
6. Through holes on the advertisement, screws into the corresponding holes on the prepared substrate advertising fixed to the substrate
7. Connect power cable with power supply in accordance with markings
8. Restore the front display on position
9. Close click frame

* Cable not included