

Servante HERCULE

940H2



Profils




Description produit

- Matière : tôle Premium Plus
- Système de verrouillage centralisé avec clé repliable
- Serrure à clé, un porte clé inclu
- Roues de diamètre 125 mm, dont 2 avec frein, résistantes à l'huile et aux acides
- Tiroirs coulissants avec glissières à roulement à billes.
- L'ouverture et fermeture des tiroirs grâce aux loquets intégrés s'effectue simplement en saisissant les poignées.
- Intérieur des tiroirs recouvert d'une surface synthétique antidérapante
- Laque éco à la norme QualiCoat
- 7 tiroirs de face : 5 dim L 563 x P 365 x H 70 mm et 2 dim L 563 x P 383 x H 150 mm

- Dimensions poignée et roues incluses : L 1182 x l 640 x H 955 mm
- Volume total des tiroirs : 133 litres
- Porte avec serrure
- Large plan de travail en bois
- Capacité de charge statique sans roue : 2300 kg
- Capacité de charge dynamique des servantes : 550 kg
- Capacité de charge des tiroirs : 45 Kg
- Tiroirs compatibles avec les modules d'outils SOS 1/3, 2/3, 3/3

Avantages :

- La paroi perforée sur le côté arrière de la servante permet d'accrocher des outils grâce des crochets.
- Accessoires possibles : une étagère pour un rangement facile de bombes et spray jusqu'à 68 mm, et une porte arrière avec un verrou.



Barcode	L	L1	L2	B	B1	H	H1	Weight
615511	1182	1040	1080	640	550	955	800	96200

* Les images des produits ne sont pas contractuelles. Toutes les dimensions sont en mm, les poids en grammes.

Accessories



Panneau vertical pour outils EUROVISION



Jeu de cloisons pour petit tiroir de 940E et 940EV



Jeu de séparateurs pour tiroirs - 4 pièces pour 940E



Etagère à bombe et spray pour 940H



Porte arrière pour 940H



Module mousse SOS compartimenté



Module mousse SOS compartimenté

Pièces de rechange



Jeu de serrures + clés



Glissières de tiroir à roulement



Jeu de roues

Safety tips



- Lock all your drawers before trying to roll the tool carriage into a new work area.
- Set the brakes on the locking casters after you have rolled the cabinet to your work area.
- Treat your tool carriage, tool chests, or tool boxes with respect.
- Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.
- Always put heavier objects in the bottom drawers
- Always close drawers when not in use.
- Always follow manufacturer manual instructions regarding assembly and repair of your tools.



- Don't open two or more drawers at the same time, there is high chance of it tipping over.
- Don't throw tools into drawer, always put the tools in.
- Don't use an opened drawer as a working surface.
- Don't clean a lacquered surface with a solvent cleaner.
- Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.
- Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.
- Don't roll a tool carriage with loose tools or parts on top of the carriage.
- Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.
- Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool

carriage.

- Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.