

# Tool carriage Eurostyle

940E9




Profiles



#### **Product features**

- material: premium PLUS sheet metal
- central locking system with a lock and folding key
- lock with key included also foam keyring
- oil and acid resistant casters of a diameter of 100 mm, one with brake, which blocks spinning and swiveling of the caster
- full extension drawers with top quality ball-bearing slides

- the synthetic covering protects drawers and tools from damage
- wide range of accessories
- coated with eco colour of Qualicoat quality standard
- 8 drawers (6 x L 560 x W 365 x H 70 mm, 2 x L 560 x W 400 x H 150 mm)
- basic dimensions with handle and casters L 760 x W 500 x H 975 mm
- total volume of drawers: 153 litres
- static load capacity of carriage without casters: 1600kg
- dynamic load capacity of carriages: 300 kg
- maximum capacity of each drawer: 45kg
- drawers compatible with SOS tool trays 1/3, 2/3, 3/3



|        | L   | В   | Н   | L1  | B1  | H1  | <b>1</b> |
|--------|-----|-----|-----|-----|-----|-----|----------|
| 611757 | 770 | 500 | 975 | 700 | 440 | 847 | 59000    |

\* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

### Accessories



Tool chest Eurostyle - 3 compartments




Tool chest Eurostyle - 5 compartments



Partitions set for small drawer 940E and 940EV



Partitions set- 4 pieces for 940E



## Spare parts



Lock with keys



Ball-bearing slide, set of 1 pair



## Safety tips



• Lock all your drawers before trying to roll the tool carriage into a new work area.

• Set the brakes on the locking casters after you have rolled the cabinet to your work area.

• Treat you tool carriage, tool chests, or tool boxes with respect.

• Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.

• Always put heavier objects in the bottom drawers



• Don't open two or more drawers at the same time, there is high chance of it tipping over.

Don't throw tools into drawer, always put the tools in.

• Don't use an opened drawer as a working surface.

• Don't clean a lacquered surface with a solvent cleaner.

• Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.

• Always close drawers when not in use.

• Always follow manufacturer manual instructions regarding assembly and repair of your tools.

• Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.

• Don't roll a tool carriage with loose tools or parts on top of the carriage.

• Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.

• Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool carriage.

• Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.