

# Dropout alignment gauges

1692/4



## Profiles



## Product features

- material: premium flex plus carbon steel
- surface finish: blacken to standard DIN 50938

## How to use the tool:

- To use, remove the wheel and insert the tool into the frame. This tool is used for the alignment of the rear triangle and dropouts.



Barcode	D	B	L	Weight
618412	30	84	309,5	1222

\* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)

