


# Disc brake piston spreader

1750/2BI



## Usage




## Product attributes

- material: premium flex chrome vanadium steel
- ergonomic heavy duty double component handle
- surface finish: chrome plated to standard ISO 1456:2009
- Tool is bended under 30°.
- Use for changing bike brake pads.


## How to use the tool:

1. remove wheel from bike
2. insert spreader between brake pads, pushing tool till the both brake pistons are back in the caliper body
3. remove the spreader and old brake pads
4. insert new brake pads
5. reinstall wheel back on



Barcode	A	B	L	Icon
---------	---	---	---	------


621889	3,5	25	160,5	130
--------	-----	----	-------	-----



### Retail packaging

Barcode	MA	MB	MC	Icon
---------	----	----	----	------

621889	230	44	35	142
--------	-----	----	----	-----



### Transport packaging

Barcode	Icon	TA	TB	TC	Icon
---------	------	----	----	----	------

621889	4	95	240	64	633
--------	---	----	-----	----	-----