

Angle gauge

2213/2BI



Profiles




[\(/ar/support/warranty\)](#)

Product features


- this is used for screws on the heads of motors where car manufacturers prescribe that, as well as fastening the screws to the prescribed torque, fastening at a certain angle is also required
- if your space is limited, you can also use an extension to obtain the required height
- the scale is 360°, divided into 2° angles

How to use the tool:

- hold the angle scale by its small handle to avoid rotation during screw joining, set the indicator to zero and then fasten the screw at the prescribed angle with another tool from the 1/2" product range (e.g. a hinge handle which is longer, because the forces are considerable)




Barcode	L	B	A	C	Icon
622815	270	75	80	63	428



Retail packaging

Barcode	MA	MB	MC	Icon
622815	380	75	79	435



Transport packaging

Barcode	Icon	TA	TB	TC	Icon
622815	4	125	325	100	1895