

Angle gauge

2213/2BI



프로파일




제품 특징

- this is used for screws on the heads of motors where car manufacturers prescribe that, as well as fastening the screws to the prescribed torque, fastening at a certain angle is also required
- if your space is limited, you can also use an extension to obtain the required height
- the scale is 360°, divided into 2° angles

틀 사용 방법:

- hold the angle scale by its small handle to avoid rotation during screw joining, set the indicator to zero and then fasten the screw at the prescribed angle with another tool from the 1/2" product range (e.g. a hinge handle which is longer, because the forces are considerable)



L

B

A

C





622815

L

270

B

75

A

80

C

63



428

* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.