


# BB90 removal tool

1625/2BB90



## Usage




## Profiles




## Product attributes

- This tool is designed to remove the non-threaded bottom bracket bearings and cups of the BB90 bottom bracket system. It also supports other press fit standards with 24mm spindle, such as BB86, BB92, SRAM Press Fit GXP. The removal tool will pull the bearings & cup from the frame. Carefully insert the guide head of removal tool trough the bottom bracket cup (marked green).



Barcode	A	B	D	D1	mm	Icon
623085	55	54	26,6	24,5	13	283



### Retail packaging

Barcode	MA	MB	MC	Icon
623085	92	57	57	325

### Transport packaging

Barcode	Icon	TA	TB	TC	Icon
623085	1	92	57	57	324

### Spare parts



Plastic ring for 1625/2BB90



Guide head for 1625/2BB90