

# Serie di giraviti NI

606B5NI



### Profili



# Attributi del prodotto

#### Incluso:

• 5x giravite per viti con intaglio NI (articuli 605NI) dim. 0.4x2.0x60, 0.5x3.0x80, 0.8x4.0x100, 1.0x5.5x125, 1.2x6.5x150

Nome prodotto	SKU	Articolo	Dimensioni	Quantità
Serie di giraviti NI	617033	606B5NI	-	5
Giravite per viti con intaglio NI		605NI	0.4 x 2.0x60, 0.5 x 3.0x80, 0.8 x 4.0x100, 1.0 x 5.5x125, 1.2 x 6.5x150	5

<sup>\*</sup> Le immagini dei prodotti sono puramente simboliche. Tutte le dimensioni sono in mm, peso in grammi.

# Safety tips



- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

## Safety (pictures)







