


锤楔

812.2



配置文件



| | 812 | 812A | 820 | 820A | 810 | 830 | 817 | |
|--------|-------------------|-------------------|--------|--------|-----|-----|---------------|----|
| 609626 | 100 | 100 | 22 | 22 | | | | 2 |
| 605095 | 150, 200 | 150, 200 | 27 | 27 | | | | 30 |
| 605096 | 250, 300 | 250, 300 | 32 | 32 | | | | 30 |
| 605097 | 400 | 400 | | | | 400 | | 30 |
| 605098 | 500, 600 | 500, 600 | 40 | 40 | 700 | | | 30 |
| 605099 | 800,1000, 1250 | 800,1000, 1250 | 50, 60 | 50, 60 | | | 1000, 1250 | 30 |



605100

1500, 2000

1500, 2000

1500,
2000

30

* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.