

Double suction lifter

1944/6



Profiles



Product features

- durable plastic body
- for the transport and positioning of windshields during fitting and removing operations

Advantages:

- loading capacity: 75kg
- two strong suction pads for maximum safety
- suction pads can be set to suit flat and curved surfaces

How to use the tool:

- This lifter is useful when replacing and carrying windshields. The lifter is operated by placing the two suction pads on the windshield and creating vacuum in them by using the handles. The suction pads then securely grip the windshield that is to be removed or installed.
- 1. Position it on the windshield.
- 2. Move the handles to create vacuum between the lifter and the windshield.
- 3. The windshield can be safely removed or installed using the lifter.



* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)

