

# Piston ring compressor

2205



### **Profiles**






### **Product features**

use to install pistons on most passenger cars.

- high quality construction with sprung steel wraps
- with safety adjusting screws
- available in a wide range of sizes
- This tool is used to install pistons and piston rings into engine cylinders. Different sizes are available.

#### How to use the tool:

• Insert the piston and any piston rings into the tool, position the tool at the opening and use it to insert/push the piston and any piston rings into the cylinder.



	Н	D"	D	i	<b>②</b>
619726	80	2 1/4"- 5"	57 - 125	291	

<sup>\*</sup> Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

## Usage (pictures)







