

Electronic torque wrench

266



Profiles



Product features







- target torque warning: buzzer + 12 LED lights
- operation mode: peak hold / track
- unit selection: N-m, in-lb, ft-lb, kg-cm
- head type: interchangeable head
- gear teeth: 52
- battery: AA × 2 pcs (not included)
- battery life (continuous operation): 110 hrs.
- battery life (standby): 1 year

- data memory size: 250 inputs
- 9 preset torque settings
- operating temperature: -10°C ~ 60°C
- storage temperature: -20°C ~ 70°C
- humidity: up to 90 % non-condensing
- drop test: 1 m
- vibration test: 10G
- electromagnetic compatibility certificate
- accuracy CW: +/-2%, CCW: +/-3%
- PC connectivity
- Download data transfer program
(https://www.uniortools.com/res/files/assets/Uploads/266_calibration_program.zip)

Warranty

- warranty: 10.000 cycle / one year



					
627575	1/4"	1,5 - 30	390	9 x 12	1395
627576	1/2"	6,8 - 135	410	9 x 12	1619
627577	1/2"	10 - 200	545	14 x 18	2268

* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)



Photo (pictures)



Accessories



Ratchet insert tool for 266



Adjustable wrench insert tool for 266



Open ring insert tool for 266

Safety tips



- Only an authorised person in a certificated service centre can perform technical maintenance.
- Tools should always be serviced and calibrated by a certified service engineer.
- Tool should only be used for precise tightening as specified in the instruction manual.
- Check instruction manual on how to read the value scale on the tool properly.
- Stop tightening after hearing a feedback from the tool.
- Use only sockets with the same square drive.
- Always return the value on the scale back to 0 after usage and before storing.



Safety (pictures)

