

# Moment ključ, digitalni

266



## Profili

---



## Atributi proizvoda







- Signali upozorenja: zvuk + 12 LED
- operacija: granična vrijednost praćenja trenutka / trenutka
- mjerne jedinice: N-m, in-lb, ft-lb, kg-cm
- glava tipa: izmjenjiva glava
- broj zubnih tračnica: 52
- baterije: AA × 2 komada (nije isporučen)
- rad baterije na 110 sati
- rad baterija na mirovanju godinu dana

- spremite 250 mjerenja
- Može se postaviti 10 instanca
- Radna temperatura: -10°C ~ 60°C
- temperatura skladištenja: -20°C ~ 70°C
- Vlaga: do 90% bez kondenzacije
- ispadni test: 1 m
- test vibracija: 10G
- potvrda o elektromagnetskoj kompatibilnosti
- točnost: CW: +/- 2%, CCW: +/- 3%
- kompatibilno s vašim računalom
- Download data transfer program  
([https://www.uniortools.com/res/files/assets/Uploads/266\\_calibration\\_program.zip](https://www.uniortools.com/res/files/assets/Uploads/266_calibration_program.zip))

## Warranty

- Garancija: 10.000 mjerenja / godinu dana



					
627575	1/4"	1,5 - 30	390	9 x 12	1395
627576	1/2"	6,8 - 135	410	9 x 12	1619
627577	1/2"	10 - 200	545	14 x 18	2268

\* Slike proizvoda su simbolične. Sve dimenzije su u mm, masa je u g.

## Upotreba (pictures)



## Photo (pictures)



## Accessories



Nastavak za moment ključ 266



Podesivi ključ za moment ključ 266



Okasti ključ za moment ključ 266

## Safety tips



- Only an authorised person in a certificated service centre can perform technical maintenance.
- Tools should always be serviced and calibrated by a certified service engineer.
- Tool should only be used for precise tightening as specified in the instruction manual.
- Check instruction manual on how to read the value scale on the tool properly.
- Stop tightening after hearing a feedback from the tool.
- Use only sockets with the same square drive.
- Always return the value on the scale back to 0 after usage and before storing.



## Safety (pictures)

