

# 数显扭力扳手

266



## 配置文件

---



## 产品属性

- 目标扭矩警告:蜂鸣器+ 12 LED灯
- 运行方式:峰值保持/跟踪
- 单位选择:N-m, in-lb, ft-lb, kg-cm
- 头部类型:可换头
- 齿轮齿:52
- 电池:AA×2块(不配电池)
- 电池寿命(连续工作):110小时。
- 电池寿命(待机):1年

- 数据内存大小:250个输入
- 10档可调扭力值
- 工作温度:-10°C ~ 60°C
- 储存温度:-20°C ~ 70°C
- 湿度:高达90%不凝结
- 跌落试验:1米
- 振动试验:10 g
- 电磁兼容性的证书
- 精度CW: +/-2%, CCW: +/-3%
- 电脑连接
- Download data transfer program  
([https://www.uniortools.com/res/files/assets/Uploads/266\\_calibration\\_program.zip](https://www.uniortools.com/res/files/assets/Uploads/266_calibration_program.zip))

## Warranty

- 保修周期：1年



			L	axb	
627575	1/4"	1,5 - 30	390	9 x 12	1395
627576	1/2"	6,8 - 135	410	9 x 12	1619
627577	1/2"	10 - 200	545	14 x 18	2268

\* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

## 用途 (pictures)



## Photo (pictures)



## Accessories



266棘轮内嵌工具



可调扳手内嵌工具266



266的配套梅开扳手内嵌工具

## Safety tips



- Only an authorised person in a certificated service centre can perform technical maintenance.
- Tools should always be serviced and calibrated by a certified service engineer.
- Tool should only be used for precise tightening as specified in the instruction manual.
- Check instruction manual on how to read the value scale on the tool properly.
- Stop tightening after hearing a feedback from the tool.
- Use only sockets with the same square drive.
- Always return the value on the scale back to 0 after usage and before storing.



## Safety (pictures)

