

# Omschakelbare ratel 1/2", voor veilig werken op hoogte

190.1/1ABI-H



## Profielen

---

**Premium** *Flex*  

## Product attributen


- materiaal: premium flex chroom vanadium staal
- gesmede behuizing
- entirely hardened and tempered
- oppervlakteafwerking: verchroomd volgens ISO 1456: 2009

## Voordelen:

- non-removable riveted metal ring
- tool weight is marked on each tool
- made in accordance to the ISO 3315-B (accessories) and ISO 2725-1B (sockets) standards
- switching sockets and accessories requires use of specific tool (Art. 1111)
- sockets and accessories with side holes

## Let op!

- switching sockets and accessories must be carried out in a previously secured or safe area



626245



1/2"

L

260

A

36

B

45




456

\* Afbeeldingen van producten zijn symbolisch. Alle afmetingen zijn in mm en gewicht in gram. Alle vermelde afmetingen kunnen variëren in tolerantie.


## Gebruik (Afbeeldingen)




The carabiner on the lanyard is attached to the ring on the tool. The rings on the tools are large enough to accept 2 carabiners.



The carabiner on the lanyard has to be protected against opening using a lock ring.



Before removing the tool from the belt, unscrew the lock ring on the carabiner on the belt.



Open the carabiner on the belt and remove the tool, which is attached to a lanyard, from the carabiner on the belt. The tool is now ready for use.



Correct attachment of the tool to the lanyard. Return the tool to the belt following the steps in reverse order.



Using the socket remover (Article 1111) depress the pin in the hole while removing the socket from the square drive of the ratchet and then switch the socket or extension.

## Veiligheidstips



- Always change tools in secure areas where there is no risk of falling tools.
- Always use tools with Unior carabiners and never use carabiners with a diameter less than 6mm.



- Don't use tools without attaching them to your work belt when working at height.
- Don't use and fix damaged tools.
- Don't exceed maximum weight of 2.3kg for individual tools that a worker can attach to their belt.

- Tools being used at height should regularly be checked for damage and that there is no damage to lanyards, carabiners, attachment rings or belts.

## Veiligheid (Afbeeldingen)



## Veelgestelde vragen

### Can we use a tool for working at height as a normal tool?

A tool for working at height has the same usability as a normal tool, except that a non-removable riveted metal buckle is added to this tool.

### Does the stated weight per tool for safe work at height also include the weight of the metal ring?

The weight of the tool marked on the tool, included also weight of metal ring