

Sprocket wear indicator

1658/2P



Profielen




Product attributen

- materiaal: premium flex plus carbonstaal
- oppervlakteafwerking: verchromd volgens ISO 1456:2009
- for HG and IG sprockets

Hoe het gereedschap te gebruiken :

- The sprocket wear indicator is used to determine the condition rear sprockets. It can be used to check 12 to 21 tooth sprockets. Procedure: The chain is put on the sprocket and the tool placed with its round end between two teeth on the upper sprocket side. The last chain link is moved away from the sprocket and a force of 100 N or 10 kg is applied to the tool in the direction of sprocket rotation. Now the last chain link is moved towards the sprocket. If it skips easily to the cog the sprocket is in a good condition and will function flawlessly even with a new chain. However, if the last chain link gets stuck on the tip of the neighbouring tooth or if we have to force it to skip on the cog, the sprocket is worn out and should be replaced. In case the chain falls off the clog when applying force, the sprocket is heavily worn out and a replacement is overdue.





L

B

A

C

C''



629230

270

13

43

2,18

11/128''

77

* Afbeeldingen van producten zijn symbolisch. Alle afmetingen zijn in mm, en het gewicht in grammen. Alle vermelde afmetingen kunnen variëren in tolerantie.

Gebruik (Afbeeldingen)

