



17210A


EN

Over axle bearing press set

SL


Set za prešanje ležajev pesta

uniorbiketools.com




Set za prešanje ležajev pesta je zasnovan za prešanje ležajev v pesto, ko imamo že vstavljeno os pesta.

Over axle bearing press set is designed to install bearing over hub axles.




Glede na velikost in standard ležaja izberemo ustrezen adapter, ki ga bomo uporabili za montažo ležaja.

Determine the correct size of drift by bearing standard or size.



- Skozi os pesta vstavimo navojno palico M8, nanjo ležaj ter nad osni adapter.
- Namestite nad osne adapterje na nasprotni strani peste.

**• Insert threaded rod through the hub axle, place bearing and bearing drift onto it.
• Install drifts on the rod on the opposite side of bearing installation.**



- Na nasprotni strani montaže ležaja privijemo ročico na navojno palico.
- Na strani montaže ležaja po potrebi namestimo ustrezen distančnik in s privijanjem ročice namestimo ležaj v ležišče.

**• On the opposite site of bearing installation install the handle.
• Put the correct spacer over the bearing drift on the side of the bearing installation and turn the handle to install the bearing into the hub.**

