Odvijači CR u garnituri

607CS7CR



Profili

Opis proizvoda

Komplet sadrži:

- 4 kom. odvijača pljosnatih sa CR ručkom (art. 605CR), dim. 0.8x4.0x100, 1.0x5.5x125, 1.2x6.5x150, 1.2x8.0x175
- 3 kom. krstastih odvijača sa CR ručkom (art. 615CR), dim. PH 1x80, PH 2x100, PH 3x150

Naziv proizvoda	SKU	Artikal	Dimenzije	Količina
Odvijači CR u garnituri	617026	607CS7CR	-	7

Naziv proizvoda	SKU	Artikal	Dimenzije	Količina
Odvijač CR pljosnati		605CR	0.8 x 4.0x100, 1.0 x 5.5x125, 1.2 x 6.5x150, 1.2 x 8.0x175	4
Odvijač CR krstasti PH		615CR	PH 1x80, PH 2x100, PH 3x150	3

* Fotografije proizvoda su simbolične. Sve dimenzije su u mm, a težina u gramima. Sve navedene dimenzije mogu odstupati u granicama tolerancija.

Pravilna upotreba

- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.

- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

Bezbednost (slike)




