Ağır hizmet tipi yan keskiler, yüksekliklerde güvenli çalışma için

466/1VDP-H



Profiles

Product features

- malzeme: özel alet çeliği
- sıcak dövme, tamamen sertleştirilmiş ve temperlenmiş
- kesici ağızlar endüksiyonla sertleştirilmiştir
- yüzey bitirme: ISO 1456:2009 standardına göre krom kaplamalı
- ISO 5749 ve EN IEC 60900 standardına göre yapılmıştır

Avantajları:

- saplar ek emniyet için çift katmanlı - çift renki yalıtımla yalıtılmıştır
- Unior'un yükseklikte çalışma aletleri, araçların temel işlevlerini, ergonomisini ve kullanışlılığını korumak veya bunları mümkün olan en küçük ölçüde azaltmak için tasarlanmıştır.
- takım ağırlığı her takımın üzerinde işaretlenmiştir

Önemli!

- ikinci katmanın görünmesi halinde, VDE aletinizi yenisiyle değiştirin
- Yalıtılmış alet, karabinalarla değil, kordonlu bir kordonla kullanılmak üzere tasarlanmıştır.



		L	B	A	C	
626964	180	215	28	11	21	351

cutting capacity (10N=1kg)

		max 2150 N/mm² Ø	max 750 N/mm² Ø
626964	180	1,8	3,0

* Ürünlerin resimleri semboliktir. Bütün boyutlar mm ve ağırlık gram cinsindendir.

Usage (pictures)



The carabiner on the lanyard is attached to the ring on the tool. The rings on the tools are large enough to accept 2 carabiners.



The carabiner on the lanyard has to be protected against opening using a lock ring.



Before removing the tool from the belt, unscrew the lock ring on the carabiner on the belt.



Open the carabiner on the belt and remove the tool, which is attached to a lanyard, from the carabiner on the belt. The tool is now ready for use.



Correct attachment of the tool to the lanyard. Return the tool to the belt following the steps in reverse order.



Using the socket remover (Article 1111) depress the pin in the hole while removing the socket from the square drive of the ratchet and then switch the socket or extension.

Safety tips

- Always change tools in secure areas where there is no risk of falling tools.
- Always use tools with Unior carabiners and never use carabiners with a diameter less than 6mm.
- Tools being used at height should regularly be checked for damage and that there is no damage to lanyards, carabiners, attachment rings or belts.

- Don't use tools without attaching them to your work belt when working at height.
- Don't use and fix damaged tools.
- Don't exceed maximum weight of 2.3kg for individual tools that a worker can attach to their belt.

Safety (pictures)



Frequently asked questions

Are certified insulated tools made through a different procedure than non-certified insulated tools?
The tools are made according to the same procedure.

Are insulated (VDE) tools considered as personal protective equipment (PPE)?
According to EU regulations, VDE tools are not considered as PPE.

Is it possible to work with insulated pliers under electrical voltage?
Yes, but only by professionals who follow safety requirements and use additional personal protective equipment.

Are the VDE tools only being sampled in series production?
The high voltage test (at 10kV) is performed fully on each tool. Other tests are performed in accordance with the EN60900 standard.