Data Sheet
uniortools.com

Tool carriage Hercules

940H2-BLACK



Profiles

1,25mm Premium + QualiCoat


Product features

- material: premium PLUS sheet metal
- central locking system with a lock and folding key
- lock with key included also foam keyring
- oil and acid resistant casters of a diameter of 125mm, two with brake, which blocks spinning and swiveling of the caster
- full extension drawers with top quality ball-bearing slides
- opening and closing of drawers is very simple due to the uniform solution - drawer handle on the upper side enables users a synchronic grip and opening of a carriage drawer.
- drawers with non-slip interior synthetic lining
- coated with eco colour of Qualicoat quality standard
- 7 front drawers (5x L 563 x W 365 x H 70mm, 2x L 563 x W 383 x H 150mm)

- basic dimensions with handle and casters L 1182 x W 640 x H 955 mm
- total volume of drawers: 133 litres
- door with lock
- wooden worktop
- static load capacity of carriages without casters: 2300 kg
- dynamic load capacity of carriages: 550 kg
- capacity of front drawers: 45 kg
- drawers compatible with SOS tool trays 1/3, 2/3, 3/3

Advantages

- Perforated wall on the back side of the tool carriage allows hanging tools with tool hooks
- As an accessories available also a spray holder for easy storage of sprays up to dia. 68mm, and a back door with a lock



	L	L1	L2	B	B1	H	H1	
628212	1182	1040	1080	640	550	955	800	96200

* Images of products are symbolic. All dimensions are in mm, and weight is in grams. All listed dimensions may vary in tolerance.

Accessories

 Partitions set for small drawer 940E and 940EV


 Partitions set- 4 pieces for 940E

 Empty SOS tool tray for 940PLUS, 940EM, 940H, 940E and 940EV

 Empty SOS tool tray for 920PLUS, 940E and 940EV

Spare parts

 Set of locks with keys

 Ball-bearing slide, set of 1 pair

 Set of casters

Safety tips

● Lock all your drawers before trying to roll the tool carriage into a new work area.

● Set the brakes on the locking casters after you have rolled the cabinet to your work area.

● Treat you tool carriage, tool chests, or tool boxes with respect.

● Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.

● Always put heavier objects in the bottom drawers

● Always close drawers when not in use.

● Always follow manufacturer manual instructions regarding assembly and repair of your tools.

● Don't open two or more drawers at the same time, there is high chance of it tipping over.

● Don't throw tools into drawer, always put the tools in.

● Don't use an opened drawer as a working surface.

● Don't clean a lacquered surface with a solvent cleaner.

● Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.

● Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.

● Don't roll a tool carriage with loose tools or parts on top of the carriage.

● Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.

● Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool carriage.

● Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.