# Izvijači CR u garnituri

607CS7CR




## Profili

## Atributi proizvoda

### Komplet sadrži:

- 4x flat screwdriver CR (article 605CR) dim. 0.8x4.0x100, 1.0x5.5x125, 1.2x6.5x150, 1.2x8.0x175
- 3x crosstip (PH) screwdriver CR (article 615CR) dim. PH 1x80, PH 2x100, PH 3x150

| Ime proizvoda | SKU | Članak | Dimenzije | Količina |
|---|---|---|---|---|
| Izvijači CR u garnituri | 617026 | 607CS7CR | - | 7 |
| Izvijač plosnati CR | | 605CR | 0.8 x 4.0x100, 1.0 x 5.5x125, 1.2 x 6.5x150, 1.2 x 8.0x175 | 4 |

| Ime proizvoda | SKU | Članak | Dimenzije | Količina |
|---|---|---|---|---|
| Izvijač križni (PH) |  | 615CR | PH 1x80, PH 2x100, PH 3x150 | 3 |

* Slike proizvoda su simbolične. Sve dimenzije su u mm, masa je u g.

## Safety tips

- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.

- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

### Safety (pictures)




