

Tool carriage Eurovision

940EV4



Profiles




Product features

- material: premium PLUS sheet metal
- wide range of accessories
- blind nuts for fixing accessories are mounted on the carriage.
- static load capacity of carriage without casters: 1600kg
- maximum capacity of each drawer: 45kg
- 7 drawers (5x L 563 x W 365 x H 70mm, 2x L 563 x W 383 x H 150mm)
- basic dimensions with handle and casters L 800 x W 440 x H 923mm
- total volume of drawers: 140 litres

• drawers compatible with SOS tool trays 1/3, 2/3, 3/3

Advantages:

- coated with eco colour of Qualicoat quality standard
- opening and closing of drawers is very simple due to the uniform solution drawer handle on the upper side enables users a synchronic grip and opening of a carriage drawer.
- drawer closing mechanism prevents unwanted opening of drawers
- drawers with non-slip interior synthetic lining
- central locking system with a lock and folding key
- lock with key included also foam keyring
- full extension drawers with top quality ball-bearing slides
- oil and acid resistant casters of a diameter of 125mm, one with brake, which blocks spinning and swiveling of the caster
- dynamic load capacity of carriages: 500 kg



	L	В	H	L1	H1		
619885	800	440	923	700	768	57000	

* Images of products are symbolic. All dimensions are in mm, and weight in grams. All listed dimensions may vary in tolerance.

Usage (pictures)



Accessories





Sheet metal basket for 940EV



Paper holder for 940EV



Holder for bottles for 940EV



Partitions set for small drawer 940E and 940EV



Partitions set- 4 pieces for 940E



Document holder for 940E and 940EV




Holder for bottles for 940E and 940EV



ABS plate for 940E and 940EV

Wooden plate for 940E and 940EV



Empty SOS tool tray for 940PLUS, 940EM, 940H, 940E and 940EV

Empty SOS tool tray for 920PLUS, 940E and 940EV

Spare parts



Lock with keys



Ball-bearing slide, set of 1 pair

Set of casters





• Lock all your drawers before trying to roll the tool carriage into a new work area.

• Set the brakes on the locking casters after you have rolled the cabinet to your work area.

• Treat you tool carriage, tool chests, or tool boxes with respect.

• Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.

• Always put heavier objects in the bottom drawers

• Always close drawers when not in use.

• Always follow manufacturer manual instructions regarding assembly and repair of your tools.



• Don't open two or more drawers at the same time, there is high chance of it tipping over.

• Don't throw tools into drawer, always put the tools in.

• Don't use an opened drawer as a working surface.

• Don't clean a lacquered surface with a solvent cleaner.

• Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.

• Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.

• Don't roll a tool carriage with loose tools or parts on top of the carriage.

• Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.

• Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool carriage.

• Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.