
# Stega bravarska IRONGATOR sa brzim sistemom pomeranja


721Q/6



## Profili

## Opis proizvoda

- kućište od sivog liva
- čeljusti od ugljeničnog čelika, kovane i poboljšane
- kućište lakirano, čeljusti zaštićene od korozije, ostali delovi presvučeni cinkom
- uniPRO vođice omogućavaju precizan rad pokretnih delova
- ova stega može se lako kombinovati sa okretnim postoljem
- sistem brzog pomeranja




| | B | L | L | D | H1 | a | b | H | L1 | B1 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 621482 | 125 | 120 | 336 | 17 - 62 | 95 | 66 | 44 | 176 | 132 | 90 | 14500 |
| 621568 | 150 | 140 | 400 | 20 - 75 | 117 | 80 | 53 | 211 | 154 | 105 | 23500 |

* Fotografije proizvoda su simbolične. Sve dimenzije su u mm, a težina u gramima. Sve navedene dimenzije mogu odstupati u granicama tolerancija.

### Upotreba (slike)






## Dodatna oprema


Okretno postolje za stege 721/6 i 721Q/6


Rezervne čeljusti za 721/6 i 722/6, aluminijumske

## Rezervni delovi


Rezervne čeljusti za 721/6 i 721Q/6


Rezervne čeljusti za 721/6 i 722/6, aluminijumske

## Pravilna upotreba

- Avoid clamping with heavy pressure on the corner of the vice jaws as it may break off a corner of a jaw.
- Replace a bent handle as soon as possible.
- Use bolts in all of the holes in the base of the vice.
- Use lock washers under the nuts.
- When work is held in a vice for sawing, saw as close to the jaws as possible to prevent vibrations. Be careful not to cut into the jaws.
- When clamping extra long work, support the far end of work rather than putting extra pressure on the vice.
- Regularly lightly oil all moving parts.
- If the threaded part of the vice is exposed, keep it free of chips and dirt.
- Discard any vice that exhibits the slightest hairline fracture.
- Always use a vice large enough to hold the work without strain.
- Don't use the jaws of a vice as an anvil.
- Never use an extension handle for extra clamping pressure.
- Never pound on the handle to tighten beyond hand pressure.
- Never try to repair a vice by welding or brazing.
- Don't try to bend a heavy rod in a light vice.