Quick IRONGATOR engineer's vice with quick moving system


721Q/6-US



配置文件

产品属性

- 外壳主体由灰口铸铁铸造
- 锻造的碳素工具钢钳口，淬火与回火处理
- 主体喷漆，钳口途防腐油，其他部分镀锌
- uniPRO滑动轴确保移动部件的精确运行
- 专业的台虎钳结合旋转底座
- 快速移动系统



	B	L	L	D	H1	a	b	H	L1	B1	
625130	125	120	336	17 - 62	95	66	44	176	132	90	14500
625131	150	140	400	20 - 75	117	80	53	211	154	105	23500

* Images of products are symbolic. All dimensions are in mm, and weight is in grams. All listed dimensions may vary in tolerance.

Accessories


721/6 和721Q/6用旋转底座


721/6和721Q/6用备用铝制夹钳

配件


721/6和721Q/6用备用夹钳


721/6和721Q/6用备用铝制夹钳

Safety tips

- Avoid clamping with heavy pressure on the corner of the vice jaws as it may break off a corner of a jaw.
- Replace a bent handle as soon as possible.
- Use bolts in all of the holes in the base of the vice.
- Use lock washers under the nuts.

- Don't use the jaws of a vice as an anvil.
- Never use an extension handle for extra clamping pressure.
- Never pound on the handle to tighten beyond hand pressure.
- Never try to repair a vice by welding or brazing.
- Don't try to bend a heavy rod in a light vice.

- When work is held in a vice for sawing, saw as close to the jaws as possible to prevent vibrations. Be careful not to cut into the jaws.
- When clamping extra long work, support the far end of work rather than putting extra pressure on the vice.
- Regularly lightly oil all moving parts.
- If the threaded part of the vice is exposed, keep it free of chips and dirt.
- Discard any vice that exhibits the slightest hairline fracture.
- Always use a vice large enough to hold the work without strain.