


Base rotante per 721/6 e 721Q/6

721.1/6







Profili



Attributi del prodotto

- piastra base in ghisa grigia
- materiale per altre parti: acciaio speciale per utensili
- possibilità di ruotare di 360° la base girevole



|  |  | L | B | H | B1 | L1 | D |  |
|---|--|-------|-------|------|-----|-----|------|--|
| 621566 | 80 | 96 | 96 | 47 | 81 | 81 | 6.5 | 2570 |
| 621483 | 125 | 149.9 | 149.9 | 70 | 126 | 126 | 10.5 | 2590 |
| 621569 | 150 | 190 | 190 | 87.5 | 160 | 160 | 13 | 5190 |
| 621572 | 200 | 210 | 210 | 93.5 | 176 | 176 | 13 | 6600 |

* Le immagini dei prodotti sono puramente simboliche. Tutte le dimensioni sono in mm, peso in grammi.

Safety tips



- Avoid clamping with heavy pressure on the corner of the vice jaws as it may break off a corner of a jaw.
- Replace a bent handle as soon as possible.
- Use bolts in all of the holes in the base of the vice.
- Use lock washers under the nuts.
- When work is held in a vice for sawing, saw as close to the jaws as possible to prevent vibrations. Be careful not to cut into the jaws.
- When clamping extra long work, support the far end of work rather than putting extra pressure on the vice.
- Regularly lightly oil all moving parts.
- If the threaded part of the vice is exposed, keep it free of chips and dirt.
- Discard any vice that exhibits the slightest hairline fracture.
- Always use a vice large enough to hold the work without strain.



- Don't use the jaws of a vice as an anvil.
- Never use an extension handle for extra clamping pressure.
- Never pound on the handle to tighten beyond hand pressure.
- Never try to repair a vice by welding or brazing.
- Don't try to bend a heavy rod in a light vice.