

# Kaçavidë plus (PZ) CR,i shkurtë

628TBI



#### **Profiles**




#### Standards

ISO 8764-1,2

## **Product features**

- teh: çeliku krom-molibden vanadium-, thekur tërësisht dhe nevrik
- krom kromuar teh, nxihem majën
- trajtuar: formë ergonomik
- tre material komponent
- varur vrimë
- bërë sipas standardit ISO 8764-1,2













	+	C	L	D	•	
612837	PZ 1	25	87	4.5	37	
617095	PZ 2	35	97	6.0	43	

<sup>\*</sup> Imazhet e produkteve janë simbolike. Të gjitha dimensionet janë në mm, pesha në gram. Të gjitha dimensionet e listuara mund të ndryshojnë në tolerancë.

# Safety tips



- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

# Safety (pictures)









# Frequently asked questions

### Can you hit the screwdriver?

No, you should not hit the screwdriver.

#### How do we clean a multi-component handle?

With cleaning agents designed for PP/TPE material.

# Can a screwdriver with a PH tip be used for PZ cross head screws? Its use is not recommended as this can cause damage to the screw.