

# Kolica za alat Hercules

940H1



## Profili




## Atributi proizvoda

- materijal: Premium Plus lim
- sa sistemom zaključavanja
- lock with key included also foam keyring
- kotači otporni na ulja i kiseline prečnika 125mm, jedan sa kočnicom, koja blokira rotaciju točka
- police sa kugličnim vodilicama
- sistem otvaranja i zatvaranja ladica vrlo je jednostavan zbog inovativnog rješenja, nudi korisniku istovremeno prihvat i otvaranje ladica
- sintetičke podloge štite ladice i alat od oštećenja
- obložena eko bojom QualiCoat standard kvalitetom
- 7 prednjih ladica (5x D 563 x Š 365 x V 70mm, 2x D 563 x Š 383 x V 150mm)

- 7 bočnih ladica (5x D 374 x Š 364 x V 70mm, 2x D 374 x Š 364 x V 150mm)
- osnovne dimenzije sa ručkom i točkama L 1182 x W 640 x H 955 mm
- ukupna zapremina ladice: 215 litara
- drvena radna površina
- statička nosivost kolica bez kotača: 2300kg
- dinamički nosivost: 550 kg
- nosivost bočnih ladica: 25kg
- nosivost prednjih ladica: 45kg
- ladice kompatibilne sa SOS alatima 1/3, 2/3, 3/3

#### Prednosti:

- Sporedni dio kolica je izrađen od perforiranog lima, koji nudi mogućnost vješanja alata uz pomoć kuka
- Osim toga, tu je i držač spreja za skladištenje sprejeva do promjera 68 mm i sporedna vrata s bravom




	L	L <sub>1</sub>	L <sub>2</sub>	B	B <sub>1</sub>	H	H <sub>1</sub>	
615510	1182	1040	1080	640	550	955	800	115600

\* Slike proizvoda su simbolične. Sve dimenzije su u mm, masa je u g.

#### Upotreba (pictures)



#### Accessories



Pano za alat za kolica 940H



Garnitura pregrada za male ladice od 940E i 940EV



Garnitura pregrada za art. 940E i 940EV, četverodijelne



Držač spreja za 940H



Zadnja vrata za 940H



SOS uložak za alat - prazan, za 920PLUS, 940E i 940EV




SOS uložak za alat - prazan, za 920PLUS, 940E i 940EV

## Rezervni dijelovi



Komplet brava sa ključevima



Klizni držač 940E1-9



Set točkova

## Safety tips



- Lock all your drawers before trying to roll the tool carriage into a new work area.
- Set the brakes on the locking casters after you have rolled the cabinet to your work area.
- Treat your tool carriage, tool chests, or tool boxes with respect.
- Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.
- Always put heavier objects in the bottom drawers
- Always close drawers when not in use.



- Don't open two or more drawers at the same time, there is high chance of it tipping over.
- Don't throw tools into drawer, always put the tools in.
- Don't use an opened drawer as a working surface.
- Don't clean a lacquered surface with a solvent cleaner.
- Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.

- Always follow manufacturer manual instructions regarding assembly and repair of your tools.

- Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.

- Don't roll a tool carriage with loose tools or parts on top of the carriage.

- Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.

- Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool carriage.

- Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.