

# Serie di giraviti CR

609CS7CR





## Profili



## Attributi del prodotto

### Incluso:

- 4x giravite per viti con intaglio CR (articoli 605CR) dim. 0.8x4.0x100, 1.0x5.5x125, 1.2x6.5x150, 1.2x8.0x175
- 3x giravite a doppia croce (PZ) CR (articoli 625CR) dim. PZ 1x80, PZ 2x100, PZ 3x150

Nome prodotto	SKU	Articolo	Dimensioni	Quantità
Serie di giraviti CR	617030	609CS7CR	-	7
Giravite per viti con intaglio CR		605CR	0.8 x 4.0x100, 1.0 x 5.5x125, 1.2 x 6.5x150, 1.2 x 8.0x175	4
Giravite a doppia croce (PZ) CR		625CR	PZ 1x80, PZ 2x100, PZ 3x150	3

\* Le immagini dei prodotti sono puramente simboliche. Tutte le dimensioni sono in mm, peso in grammi.

# Safety tips



- Use a screw holding screwdriver to get screws started in awkward, hard-to-reach areas.
- Use a stubby screwdriver in close quarters where a conventional screwdriver cannot be used.
- A rounded tip should be redressed with a file; make sure edges are straight.
- Screwdrivers used in the shop are best stored in a rack. This way, the proper selection of the right screwdriver can be quickly made.
- Keep the screwdriver handle clean; a greasy handle is apt to cause accidents.
- A screwdriver should never be used as pry bar. If it is overstressed in this manner, the blade might break and send a particle of steel into the operator's arm or even towards his eyes.



- Don't use pliers on the handle of a screwdriver to get extra turning power. A wrench should only be used on the square shank or bolster of a screwdriver that is especially designed for that purpose.
- Don't expose a screwdriver blade to excessive heat as it may reduce the hardness of the blade.
- Don't use a screwdriver with a split or broken handle.
- Don't use a regular screwdriver to check a storage battery or to determine if an electrical circuit is live.

## Safety (pictures)

