

Qëndroni me pjatë fikse dhe nofullën me arrë rregullueshme

1693BS-US










Profiles



Product features

- Riparimi qëndrojnë biçikletë me pjatë të caktuar është projektuar për punëtori të shërbimit dhe çdo përdorim ditë.
- Pjatë fikse është projektuar ergonomike. Kapaciteti maksimal i ngarkesës është 30kg, e cila mundëson shërbimin e biçikletë rëndë.
- I përshtatshëm për tuba me diametër prej min. Ø24 mm dhe max. Ø40 mm.
- Pesha e standës është 36 kg
- Zë vendin nofulla gome mbulon, pika 1693,11



| | | | | | | |
|--|---|---|---|---|---|---|
|  |  |  |  |  |  |  |
| 625013 | 985 | 1570 | 726 | 572 | 1700 | 38800 |

* Imazhet e produkteve janë simbolike. Të gjitha dimensionet janë në mm, pesha në gram. Të gjitha dimensionet e listuara mund të ndryshojnë në tolerancë.

Usage (pictures)



Adjust bike stand height? To adjust the bike stand height, release the lever (C) and adjust the top tube (D).



Adjust jaw angle and clamp bike safely? To adjust the bike stand jaw angle, release lever (F) and adjust/rotate (E).



Adjust opened jaw (G) to the seatpost or bike tube. Turn handle (H) until jaw firmly grabs the tube.



To adjust the jaw opening, turn the long screw (Z) with hand in needed direction as shown on picture.



Release bike safely from stand? To release, firmly hold bike frame. Flip handle (I) to quickly release tube from the jaw.



To mount the stand without fixed plate to the floor or ceiling, use appropriate screw anchors and screws (P) according to the floor/ceiling material, as shown on picture. Screws and screw anchors are not included.