

Kolica za alat "Hercules" s blok sistemom

940H2BLOCK



Profili




Atributi proizvoda



- materijal: Premium Plus lim
- s centralnim sistemom zaključavanja
- Brava sa ključem i privjeskom
- NOVO Blok sigurnosni sustav sprječava otvaranje više od jedne ladice odjednom. Kada je jedna ladica otvorena, sve ostale ladice su zaključane i ne mogu se otvoriti.
- 4 kotača, 2 s kočnicom
- police s kugličnim vodilicama

- Sistem otvaranja i zatvaranja ladica vrlo je jednostavan zbog inovativnog rješenja, nudi korisniku istovremeno prihvat i otvaranje ladica
- sintetičke podloge štite ladice i alat od oštećenja
- 7 prednjih ladica dimenzija 560x365mm (5 visine 70mm i 2 visine 150mm)
- Osnovne dimenzije sa ručkom i točkama L 1182 x W 640 x H 955 mm
- Ukupni volumen ladica: 133 L
- Vrata s bravicom
- Drvena radna površina
- Statička nosivost kolica bez kotača: 2300kg
- Dinamička nosivost: 550 kg
- nosivost prednjih ladica: 45kg
- Ladice kompatibilne sa SOS alatima 1/3, 2/3, 3/3

Prednosti:


- Zadnja strana kolica je iz perforiranog lima, koji nudi mogućnost vješanja alata uz pomoć kukica
- Kao dodatak na raspolaganju nam je nosač sprejeva, koji omogućuju pohranu sprejeva do promjera od 68 mm te stražnja vrata s bravom




	L	L1	L2	B	B1	H	H1	
626800	1182	1040	1080	640	550	955	800	96200

* Slike proizvoda su simbolične. Sve dimenzije su u mm, masa je u g.

Accessories



Pano za alat za kolica 940H



Garnitura pregrada četverodijelna za male ladice za 940E i 940EV



Garnitura pregrada za art. 940E i 940EV, četverodijelne



Nosač sprejeva za 940H



Vrata za kolica 940H



SOS uložak za alat - prazan, za 940PLUS, 940EM, 940H, 940E i 940EV



SOS uložak za alat - prazan, za 920PLUS, 940E i 940EV

Rezervni djelovi



Set of locks with keys



Ball-bearing slide for tool carriage with BLOCK system, set of 1 pair



Set of casters

Safety tips



- Lock all your drawers before trying to roll the tool carriage into a new work area.
- Set the brakes on the locking casters after you have rolled the cabinet to your work area.
- Treat your tool carriage, tool chests, or tool boxes with respect.
- Always follow the prescribed max load capacity of individual drawers and the carriage as a whole.
- Always put heavier objects in the bottom drawers
- Always close drawers when not in use.
- Always follow manufacturer manual instructions regarding assembly and repair of your tools.



- Don't open two or more drawers at the same time, there is high chance of it tipping over.
- Don't throw tools into drawer, always put the tools in.
- Don't use an opened drawer as a working surface.
- Don't clean a lacquered surface with a solvent cleaner.
- Don't pull a tool carriage as you won't be able to see where you are headed. Push it in front of you so you can see where you are going.
- Don't stack a tool carriage with too many extra chests or tool trays; it may tip over at the most unexpected time.
- Don't roll a tool carriage with loose tools or parts on top of the carriage.
- Don't roll a tool carriage too quickly; a pot hole in the floor or some hardware on the floor may cause an accident.
- Don't overload the drawers; if you haven't got room for all of your tools, you need a larger tool

carriage.

- Don't open up too many loaded drawers at a time; close each drawer before opening up another. Heavily loaded opened drawers are an invitation to tipping.

Frequently asked questions

What does it mean if the tool carriage has the word BLOCK on the item label?

This means that it has a system of guides that makes it impossible to have two drawers open at the same time.