



Unior d.d.
Kovaška cesta 10
3214 Zreče, Slovenia
T: +386 3 757 81 00
F: +386 3 576 26 43
bike@unior.com
www.uniorbiketools.com



1693C

EN

Repair bike stand with
two jaws


SLO

Stojalo za servisiranje
koles z dvema glavama


 **UNIOR**[®]
BIKE TOOLS

uniorbiketools.com

BIKE STAND PREPARATION




To adjust bike stand height, release lever (A) and adjust the height of stand tube (B) • Za nastavitev višine stojala sprostite vzvod (A) in nato nastavite željeno višino (B) stojala.




To adjust bike stand head position, release lever (C) and adjust/rotate the head (D) • Za nastavitev glave stojala sprostite vzvod (C) in nato nastavite željeno pozicijo (D) glave stojala.

CLAMPING BIKE



Adjust opened jaws (E) to seatpost or bike tube. Turn handle (F) until jaws firmly grabs the tube • Nastavite odprto čeljust (E) sedežno oporo ali cev okvirja. Obrnite ročaj (F) dokler čeljusti ne zajamejo celotne cevi.

RELEASING BIKE



Firmly hold bike frame (G). Flip handle (H) to quickly release tube from jaws • Trdno primite okvir kolesa (G). Obrnite ročaj (H) za hitro sprostitev cevi iz čeljusti orodja.

WARNING

1. Some bike manufacturers recommend not clamping thin-walled carbon fiber frames. Consult manufacturer for suggested clamping location.
2. To avoid damage to the seatpost or bike frame, always clean the clamping position on the bike and the jaws before clamping.

OPOZORILO

1. Nekateri proizvajalci koles priporočajo da tanjših karbonskih koles ne vpenjate. Posvetujte se z vašim proizvajalcem koles za pravilno uporabo.
2. Da se izognete poškodbam okvirja ali sedežne opore kolesa, vedno očistite mesto vpenjanja in čeljust stojala.